


METER



Color code

W	White	Dg	Dark green
Br	Brown	Ch	Dark brown
Y	Yellow	G/W	Green/white
G	Green	Br/W	Brown/white
B	Black	Y/W	Yellow/white
R	Red	G/Y	Green/Yellow
P	Pink	B/R	Black/Red
L	Blue	B/W	Black/White
Sb	Sky blue	L/W	Blue/White

Dave Riley

Main switch

	B	B/W	B	B
OFF	○	○	○	○
ON	○	○	○	○

Flasher switch

	Dg	B/W	Ch
R	○	○	○
N	○	○	○
L	○	○	○

Horn switch

	P	EARTH
PRESS	○	○
PUSH	○	○

Beam control switch

	Y	Y/W	G
HIGH	○	○	○
LOW	○	○	○

Yamaha DT250E Wiring Diagram.